

## Table of contents

Retain variable - RETAIN

# Retain variable - RETAIN

#### Retain variable - RETAIN

Retain variables are declared by the keyword RETAIN is added in programming objects in the scope VAR, VAR INPUT, VAR\_OUTPUT, VAR\_IN\_OUT, VAR\_STAT, or VAR\_GLOBAL.

## Syntax bei der Deklaration

```
<scope> RETAIN
  <identifier>: <data type> ( := <initialization> )? // ( ... )? : Optional
END VAR
<scope> : VAR | VAR_INPUT | VAR_OUTPUT | VAR_IN_OUT | VAR_STAT | VAR_GLOBAL
```

Assignment of input, output or memory addresses with the keyword AT is not allowed.

# Example In einer POU: VAR RETAIN iVarRetain: INT; END\_VAR In einer GVL:

VAR GLOBAL RETAIN g\_iVarRetain: INT; END\_VAR

## Possible declaration locations

Locally in a Only the variable lies within the retain memory area. program

Info: When using redundancy, the entire program with all its data resides in

the retain memory area.

Bosch Rexroth AG Page 1



Only the variable lies within the retain memory area.  Info: When using redundancy, the entire global variable list with all its data can be found in the retain memory area.
The entire instance of the function block with all of its data lies within the retain memory area. Only the declared retain variable is protected.
The variable is not within the retain memory area. This declaration does not have any effect.
The variable is not within the retain memory area. This declaration does not have any effect.



Whenever possible, avoid marking variables of a function block with RETAIN.

# Also refer to

- lacktriangledown "Declaring VAR PERSISTENT Variables"
- ` "Command 'Add all instance paths'"
- > "Preserving Data with Retain Variables"

Bosch Rexroth AG Page 2