

Table of contents

- Digital inputs: Image (0x2A20:01 / P-0-0307 / --)

Digital inputs: Image (0x2A20:01 / P-0-0307 / --)

Function

"P-0-0307" is an axis parameter and it exists once per drive address. "P-0-0307" is a bit word. Bit 0 correlates with the first element in the list "P-0-03003", etc. This parameter shows the states of the external inputs at the device. "P-0-0307" is used as a display and cannot be written.