## Table of contents


- MCI state machine: C0100 Safe-Op transition check (0x2C04:01 / S-0-0127 / --)


# MCI state machine: C0100 Safe-Op transition check (0x2C04:01 / S-0-0127 / --)

## Function

When executing the command "S-0-0127", all interface parameters are checked for validity.

See also “Sercos”

## Use

If there are invalid interface parameters, the drive will

- complete the command with an error message, and
- enter the invalid parameters in parameter "S-0-0021, Invalid operation data Safe-Operational transition check".
- display a C01xx diagnostic message