

## Table of contents

- Sercos protocol: Slave delay (P/S) (0x2D00:03 / S-0-1016 / --)

Sercos protocol: Slave delay (P/S) (0x2D00:03 / S-0-1016 / --)

## Function

After the master has transferred the entire ring delay (S-0-1015 (/redirect/patternMatch?code=S-0-1015&redirectOrigin=ID1769503\_117041075)) to the slaves, the slaves can determine the SYNCNT-P/S. These two delay times (P in first and S in second element) are applied to determine the physical or of the slaves in the ring or line.

See also “Sercos”

